

Weymouth Series Pressurisation Units

Installation, Commissioning and Servicing Instructions

Weymouth Standard & Advanced Models

IMPORTANT NOTE

**THESE INSTRUCTIONS MUST BE READ
AND UNDERSTOOD BEFORE INSTALLING,
COMMISSIONING, OPERATING OR
SERVICING EQUIPMENT**

Customer Services

Technical Enquiries



01202 662527/662528

To supplement the detailed technical brochures, technical advice on the application and use of products in the Hamworthy Heating range is available from our technical team in Poole and our accredited agents.

Site Assembly



01202 662555

Hamworthy offer a service of site assembly for many of our products in instances where plant room area is restricted. Using our trained staff we offer a higher quality of build and assurance of a boiler built and tested by the manufacturer.

Commissioning



01202 662555

Commissioning of equipment by our own engineers, accredited agents or specialist sub – contractors will ensure the equipment is operating safely and efficiently.

Maintenance Agreements



01202 662555

Regular routine servicing of equipment by Hamworthy service engineers inspects the safety and integrity of the plant, reducing the risk of failure and improving performance and efficiency. Maintenance agreements enable our customers to plan and budget more efficiently.

Breakdown service, repair, replacement



01202 662555

Hamworthy provide a rapid response breakdown, repair or replacement service through head office at Poole and accredited agents throughout the UK.

Spare Parts



01202 662525

A comprehensive spare parts service is operated from our factory in Poole, providing replacement parts for both current and discontinued products. Delivery of parts and components is normally from stock within seven days. However, a next day delivery service is available for breakdowns and emergencies.

Weymouth Series Pressurisation Units

Installation, Commissioning and Servicing Instructions

Weymouth Standard & Advanced Models

**NOTE: THESE INSTRUCTIONS MUST BE READ AND UNDERSTOOD BEFORE
INSTALLING, COMMISSIONING, OPERATING OR SERVICING EQUIPMENT.**

**THE WEYMOUTH PRESSURISATION UNITS ARE INTENDED FOR USE ONLY IN
COMMERCIAL/LIGHT INDUSTRIAL APPLICATIONS.**

THESE PRESSURISATION UNITS COMPLY WITH THE ESSENTIAL REQUIREMENTS OF THE MAHINERY DIRECTIVE 89/392/EEC AMENDED BY 91/368/EEC, THE LOW VOLTAGE DIRECTIVE 73/23/EEC AMENDED BY 93/68/EEC AND THE ELECTROMAGNETIC COMPATIBILITY DIRECTIVE 89/336/EEC AMENDED BY 91/263/EEC AND 92/31/EEC.

**PUBLICATION NO. 500001112
ISSUE 'C'
JUNE 2008**

CONTENTS

| | PAGE |
|--|-------------|
| 1.0 INTRODUCTION | 1 |
| 2.0 TECHNICAL DATA | 1 |
| 3.0 SEALED SYSTEM FUNCTION..... | 2 |
| 3.1 Terminology | 2 |
| 3.2 Application | 3 |
| 4.0 OPERATION OF THE PRESSURISATION UNIT..... | 4 |
| 4.1 Unit Operation..... | 4 |
| 4.2 Safety Functions (Advanced Only) | 4 |
| 5.0 GENERAL REQUIREMENTS | 4 |
| 5.1 Related Documents | 4 |
| 5.2 Mains Water Connections..... | 5 |
| 5.3 Expansion Vessels | 5 |
| 5.4 Safety Relief Valve | 5 |
| 6.0 INSTALLATION..... | 6 |
| 6.1 Location | 6 |
| 6.2 Pipework Connections..... | 6 |
| 6.3 Electrical Connection | 7 |
| 6.3.1 Mains Connection | 7 |
| 6.3.2 Safety Switches/Circuits On Advanced Only..... | 7 |

| | | |
|-------------|---|-----------|
| 7.0 | COMMISSIONING | 8 |
| 7.1 | Mechanical Installation | 8 |
| 7.2 | System Flushing | 8 |
| 7.3 | Electrical Installation..... | 8 |
| 7.4 | System Expansion Vessel..... | 8 |
| 7.5 | Initial Setting Of Both Standard And Advanced Units | 9 |
| 7.6 | Filling The Unit..... | 10 |
| 7.7 | Pressure Switch Adjustment..... | 10 |
| 7.7.1 | Pressure Switch Adjustment Apparatus | 11 |
| 7.7.2 | Cold Fill Pressure Switch..... | 11 |
| 7.7.3 | Lo Pressure Switch (Advanced Only)..... | 11 |
| 7.7.4 | Hi Pressure Switch (Advanced Only) | 11 |
| 8.0 | FAULT FINDING | 12 |
| 9.0 | SERVICING SCHEDULE | 13 |
| 9.1 | 6 Monthly | 13 |
| 9.2 | 12 Monthly | 13 |
| 9.3 | 4 Yearly | 13 |
| 10.0 | SERVICING AND REPLACEMENT OF COMPONENTS | 14 |
| 10.1 | Hamworthy Heating Recommended Spares..... | 14 |
| 10.2 | Standard Pump Removal | 14 |
| 10.3 | Advanced Pump Removal..... | 15 |
| 10.3.1 | Pump Fitting On Both Units..... | 15 |
| 10.4 | Inlet Valve On Both Units | 15 |
| 10.5 | Pressure Switches On Both Units | 16 |
| 10.6 | Pressure Gauge On Both Units..... | 16 |
| 10.7 | Non-Return Valve On Standard Unit..... | 17 |
| 10.8 | Non-Return Valve On Advanced Unit | 17 |
| 10.9 | Expansion Vessel Diaphragm | 17 |
| | APPENDIX 'A' – Diagrams, drawings and Data | 18 |

FIGURES**PAGE**

| | | |
|------------|--|----|
| Figure 1 | Basic Overall Dimensions..... | 1 |
| Figure 2 | Technical Data..... | 2 |
| Figure 3 | Typical System Schematic Layout..... | 3 |
| Figure 4 | Expansion Vessel Operation..... | 3 |
| Figure 5 | Schematic Layout of the Standard and Advanced Units..... | 4 |
| Figure 6 | Hamworthy Heating Expansion Vessels..... | 5 |
| Figure 7 | Recommended Clearance Dimensions..... | 6 |
| Figure 8 | Mounting Bracket Dimension..... | 6 |
| Figure 9 | Pipework Dimensions..... | 7 |
| Figure 10 | Advanced Alarm Terminal..... | 7 |
| Figure 11 | Restrictor Inserts Standard..... | 9 |
| Figure 12 | Restrictor Inserts Advanced..... | 9 |
| Figure 13 | Changing Advanced Restrictor Inserts..... | 9 |
| Figure 14a | Float Adjustment Standard..... | 9 |
| Figure 14b | Float Adjustment Advanced..... | 9 |
| Figure 15a | Priming Screw Standard..... | 10 |
| Figure 15b | Priming Screw Advanced..... | 10 |
| Figure 16 | Pressure Switch Adjustment..... | 10 |
| Figure 17 | Pressure Switch Adjustment Apparatus..... | 11 |
| Figure 18 | Fault Finding Guide..... | 12 |
| Figure 19 | Pump Fittings..... | 14 |
| Figure 20 | Standard Pump Wiring Terminals..... | 14 |
| Figure 21 | Advanced Pump Removal..... | 15 |
| Figure 22 | Advanced Pump Removal..... | 15 |
| Figure 23 | Advanced Pump Removal..... | 15 |
| Figure 24 | Advanced Pump Removal..... | 15 |
| Figure 25 | Weymouth Advanced Pump Wiring Terminal..... | 15 |
| Figure 26 | Capillary Nut..... | 16 |
| Figure 27 | Switch Wiring (Advanced Only)..... | 16 |
| Figure 28 | Pressure Gauge..... | 16 |
| Figure 29 | Non-Return Valve On Standard Unit..... | 17 |
| Figure 30 | Non-Return Valve On Standard Unit..... | 17 |
| Figure 31 | Non-Return Valve On Advanced Unit..... | 17 |
| Figure A1 | Wiring Diagrams..... | 19 |
| Figure A2 | Heating System Calculation Sheet..... | 20 |

1.0 INTRODUCTION

The pressurisation units in the Hamworthy Weymouth range are designed to maintain the minimum pressure requirement of modern low/medium temperature, hot water sealed systems. The pressurisation units also provide replacement water for losses from the systems.

Note! The pressurisation unit is not to be used for the initial filling of the system.

The Weymouth units are housed in a powder coated steel cabinet with removable cover. Housed in the cabinet is a pump, connecting pipe-work and pressure switches. In the top of the cabinet is the header tank, with a float valve. In the front of the cabinet is the systems pressure indication gauge.

The range has 2 models:-

1) The Standard with the following features:

Pump control pressure switch
Non-return valve
0 – 6 bar system pressure gauge

2) The Advanced with

All the features of the standard plus:
High/Low pressure switches
Isolating Valve (between tank and pump)

2.0 TECHNICAL DATA

The basic overall dimensions of both units are shown in below Figure 1, complete dimensions are shown in Figure 9 on sheet 7.

All screw threads used in the Weymouth units conform to **ISO 7/1** or **ISO 228/1** for pipe threads where applicable & **ISO 262** for all general screw threads.

Performance and General Data is shown in Figure 2 (overleaf).




Figure 2 Weymouth Pressurisation Units—Technical Data

| Model | | Standard | Advanced |
|--|--------|------------------|-----------------|
| Minimum cold fill pressure | bar | 1.0 | |
| Maximum cold fill pressure | bar | 3.4 | |
| Maximum operating pressure | bar | 7.0 | |
| Maximum Flow Rate | l/min | 6 | |
| Maximum water flow rate @ maximum cold fill pressure | l/min | 0.1 | |
| Weight (empty) | kg | 13 | 19 |
| Weight (full) | kg | 16 | 27 |
| Tank capacity | litres | 2.6 | 7.6 |
| Factory Preset Values | | | |
| Cold fill pressure | bar | 1.8 | |
| System low pressure switch | bar | - | 1.3 |
| System high pressure switch | bar | - | 3.65 |
| To suit system conditions | | | |
| Maximum water flow temp | °C | 82 | |
| Maximum static height | m | 30 | |
| Minimum system operating pressure | bar | 3.3 | |
| Maximum system operating pressure | bar | 6.3 | |
| Safety relief valve setting (Not HHL supply) | bar | 4.0 | |
| Nominal pressure differential | bar | 0.4 | |
| Electrical Data | | | |
| Pressure switch contact rating | | 15A 240V AC | |
| Electrical Supply | | 230V AC 50Hz 1Ph | |
| Start current | amps | 9 | |
| Run current | amps | 2.8 | |

3.0 SEALED SYSTEM FUNCTION

Figure 3 shows the layout of a typical sealed system.

3.1 Terminology


Expansion Vessel Charge Pressure

The gas pressure in the expansion vessel with water connection open to atmosphere

System Cold Fill Pressure

The water pressure in the system that the pressurisation unit is set to maintain


Figure 3 Typical System Schematic Layout



3.2 Application


The system expansion vessel charge pressure is set 0.1 bar below the cold fill pressure. Before operation of the boiler, with the system at cold fill pressure the expansion vessel is empty. As the system heats up the expanded volume is absorbed by the expansion vessel. A small pressure rise occurs which is accommodated by the vessel. When the system cools the pressure drops. If there has been some fluid loss the pressurisation provides replacement.

Figure 4 Expansion Vessel Operation



4.0 OPERATION OF THE PRESSURISATION UNIT

Figure 5 Schematic Layout of the Standard and Advanced Units.



4.1 Unit Operation.

A drop in system pressure due to, for example, loss of water, will cause the pump to maintain the pressure. As the level of water in the tank reduces a ball valve allows new water into the tank. When the pump pressure switch is satisfied the pump stops

4.2 Safety Functions (Advanced only):

The advanced unit is fitted with two extra pressure switches . A pressure above the high pressure limit set on the unit will switch over the SPDT high pressure switch and a pressure below the low pressure limit set on the unit will switch over the SPDT low pressure switch.

The switches can be connected to boiler safety circuits as shown in the wiring diagram supplied with the unit and displayed inside the unit's cover.

5.0 GENERAL REQUIREMENTS

5.1 Related Documents.

Pressure Systems and Transportable Gas Containers Regulations 1989.

It is the law that pressure system appliances are installed by competent persons in accordance with the above regulations. Failure to install appliances correctly could lead to prosecution. It is in your own interest and that of safety, to ensure that this law is complied with.

The installation of the pressurisation unit and expansion vessel MUST be in accordance with the relevant requirements of the Pressure System Regulations, Building Regulations, IEE Regulations and the bylaws of the local water undertaking.

It should also be in accordance with any requirements of the local authority and the relevant recommendations of the following documents:-

Applicable standards and documents are:

BS 7074 Application, selection and installation of expansion vessels and ancillary equipment for sealed water systems.

BS 6644 Installation of Gas Fired Hot Water Boilers 60 kW to 2 MW

BS 6880 Parts 1,2&3: Code of practice for low temperature hot water heating systems of output greater than 45 kW.

BS 6759 Part 1 (ISO 4126): Specification for safety valves for steam and hot water.

BS 3456 (CEE10 Part 1, CEE11 Part 1): Safety of Household and similar electrical appliances.

HSE Guidance note PM5: Automatically controlled steam and hot water boilers.

5.2 Mains Water Connections.

All connections to local water mains must comply with WRAS Regulations including any local requirements. **The System temporary fill connection must be as per water supply bylaws & must be removed after initial filling.**

5.3 Expansion Vessels.

System expansion vessels must be constructed to BS4814 or BS6144.

The required expansion vessel size is detailed in the contract documents. If these are not available refer to section 5.3.1, otherwise if in any doubt contact Hamworthy Heating Limited for comprehensive system sizing information. Hamworthy Heating Ltd supply a range of suitable expansion vessels details are shown below. A calculation sheet which can be used to determine a suitable volume for an expansion vessel can be found in the Appendix.

Figure 6 Hamworthy Heating Expansion Vessels

| SALES REF NO. | HAMWORTHY PART NO. | TYPE | TOTAL VOL. | DIAPHRAGM PART NO. | CONNECTION | WT kgs |
|---|--------------------|------------|------------|--------------------|-------------|--------|
| HOT WATER APPLICATIONS - EPDM DIAPHRAGM (0-100°C MAX) | | | | | | |
| HAF 60V | 532712002 | VERTICAL | 60 | 532712030 | R1 BSPT MI | 13 |
| HAF 80V | 532712003 | VERTICAL | 80 | 532712031 | R1 BSPT MI | 14 |
| HAF 100V | 532712004 | VERTICAL | 100 | 532712032 | R1½ BSPT MI | 15 |
| HAF 200V | 532712005 | VERTICAL | 200 | 532712033 | R1½ BSPT MI | 40 |
| HAF 300V | 532712006 | VERTICAL | 300 | 532712034 | R1½ BSPT MI | 50 |
| HAF 500V | 532712007 | VERTICAL | 500 | 532712035 | R1½ BSPT MI | 80 |
| HAF 750V | 532712008 | VERTICAL | 750 | 532712036 | R1½ BSPT MI | 120 |
| HAF 1000V | 532712009 | VERTICAL | 1000 | 532712037 | R1½ BSPT MI | 150 |
| HAF 1200V | * | VERTICAL | 1200 | * | R1½ BSPT MI | 530 |
| HAF 1600V | * | VERTICAL | 1600 | * | R1½ BSPT MI | 10 |
| HAF 2000V | * | VERTICAL | 2000 | * | R1½ BSPT MI | 700 |
| * REFER TO HAMWORTHY HEATING | | | | | | |
| HAF 8 | 532712056 | H/V | 8 | | R¾ BSPT MI | |
| HAF 16 | 532712057 | H/V | 16 | | R¾ BSPT MI | |
| HAF 25H | 532712010 | HORIZONTAL | 25 | 532712029 | R1 BSPT MI | 5 |
| HAF 60H | 532712011 | HORIZONTAL | 60 | 532712030 | R1 BSPT MI | 14 |
| HAF 80H | 532712012 | HORIZONTAL | 80 | 532712031 | R1 BSPT MI | 15 |
| HAF 100H | 532712013 | HORIZONTAL | 100 | 532712032 | R1½ BSPT MI | 16 |
| HAF 200H | 532712014 | HORIZONTAL | 200 | 532712033 | R1½ BSPT MI | 41 |
| HAF 300H | 532712015 | HORIZONTAL | 300 | 532712034 | R1½ BSPT MI | 51 |

5.4 Safety Relief Valve.


Must comply with BS6759 part 1, and be sized and installed in accordance with BS6644 & BS7074.

6.0 INSTALLATION

The units are supplied inside strong cardboard boxes with foam padding and should be left in this packaging until they arrive on site and are installed.

6.1 Location.

Figure 7 Recommended Clearance Dimensions



The units are designed for wall mounting. A mounting bracket is supplied inside the unit taped to the front of the tank. It is intended that this bracket should be fixed to the wall and the unit hung from it. Each unit also has two holes in the back of the chassis for extra security. The corresponding holes in the wall should be drilled to suit once the unit is mounted on its bracket. The bracket dimensions are shown in fig 8 below.




Figure 8 - Mounting Bracket Details

The pressurisation units can be installed on the floor if they are secured to a wall or support using screws through the holes in the chassis.

6.2 Pipework Connections (Shown in Figure 9)

1) Mains water connection ($\frac{1}{2}$ " BSP Male).

The units have a type 'AF' air gap to prevent backflow in accordance with Water Supply (Water Fittings) Regulations 1999. The water supply connection must conform to all local WRAS regulations.


2) Overflow connection (22 mm and $\frac{3}{4}$ " Female).

Overflow should be piped to where it will be safe but visible so it will be noticed and corrected.

3) System connection.

The system connection is via a 15MM compression fitting. The unit must be connected to the system by an antigravity loop (see Figure 3). The antigravity loop must be made in pipe-work no smaller than the expansion vessel connection, and have a minimum height of 2 metres. It should include a lock-shield (or lockable) valve at the system connection point for servicing and an automatic air vent fitted at the highest point of the loop. The antigravity loop must not be lagged but can be fitted with an optional kit to prevent freezing. Consult Hamworthy Heating for details. The pipe-work and fittings must be pressure tested to 1.5 times the safety valve lift pressure.

Figure 9 - Pipework Connections



6.3 Electrical connection.

Wiring diagrams for the Standard and Advanced units can be found fixed inside the cover of the unit and in the appendix. All wiring to the pressurisation unit must be in accordance with the IEE regulations, and any local regulations which apply. **Note! If in any doubt a qualified electrician should be consulted.**

6.3.1 Mains Connection

Both the Standard and Advanced are supplied fitted with a 1m flying lead for connection to the mains supply. Mains connection must be via a fused isolator rated at 13 Amps and positioned locally to the unit.

6.3.2 Safety Switches/Circuits On Advanced Only

The SPDT hi and lo pressure switches can be incorporated into circuits to interrupt a boiler control signal, in order to shut down the boiler in the event of a system fault condition. The boiler control system must be designed so that manual resetting is required after a system fault condition.

The circuits are rated at 230 V ~50 Hz, 15A. NOTE if the factory set pressure switch levels are to be altered terminal should not be connected at this stage.

The connection terminal and its location is shown in fig 10.

Figure 10 Advanced Alarm Terminal



7.0 COMMISSIONING

Weymouth Units are supplied factory set and tested to suit the system parameters shown in Figure 2. If the application falls within these parameters the unit requires minimal commissioning checks.

7.1 Mechanical Installation.

Check that the Weymouth Unit and expansion vessel has been installed correctly, as detailed in section 6.3: Pipe-work connections. Check also that all lock-shield or lockable valves are correctly set.

7.2 System Flushing.

Ensure that the system has been flushed and all foreign matter has been removed, including pipe scale.

Note! Should this material come into contact with the expansion vessel diaphragm it could result in premature failure of the expansion vessel assembly.

7.3 Electrical Installation.

Before working on Weymouth units ensure all electrical circuits connected to it are isolated.

7.4 System Expansion Vessel.

To set or check the expansion vessel charge pressure the lock-shield valve between the Weymouth unit and the vessel must be closed. The drain cock fitted on the base of the expansion vessel must be open to allow any water in the vessel to escape.

A suitable gauge should be used to check the charge pressure. Generally a Schrader 'car type' valve is fitted near the top of the expansion vessel. If the charge pressure is too high it can be reduced by depressing the centre of the Schrader valve or by using a pressure gauge with an integral air release valve. If the charge pressure is too low a small increase can be provided using a car foot pump other wise an oil free compressor or nitrogen bottle is recommended.

Note! The expansion vessel charge pressure should be set to 0.1 bar less than the cold fill pressure.

When the correct pressure is set the Schrader valve protective cap must be replaced.

Check the integrity of the pipe-work. Ensure the lock-shield valve between the Weymouth unit and the expansion vessel is open and the drain valve is closed. Ensure the air purge plug is fitted (near the top of the expansion vessel).

7.5 Initial Setting Of Both Standard And Advanced Units


- 1) Check water inlet supply, it MUST have a flow greater than 8l/min.
- 2) Flow Restrictors

Standard

Each Standard comes with a selection of inserts that can be fitted into the inlet valve to achieve the required output:

- Mains inlet pressure > 4 bar H.P. restrictor (narrow coils see fig 11)
- Mains inlet pressure < 4 bar L.P. restrictor (wide coils see fig 11)

Figure 11 Restrictor Inserts Standard



The restrictors are fitted by pushing them into the open end of the Inlet before attaching the unit to the water supply (see fig 11)

Advanced

Each Advanced comes with a selection of inserts that can be fitted into the inlet valve to achieve the required output:

- Mains inlet pressure > 4 bar H.P. restrictor (white see fig 12)
- Mains inlet pressure < 4 bar L.P. restrictor (red see fig 12)

Figure 12 Restrictor Inserts Advanced



The HP restrictor is fitted in the inlet side of the float valve assembly. This should be unscrewed in order to change the restrictor (see fig 13). The LP Restrictor is clipped to the side of the valve assembly.

Figure 13 Changing Advanced Restrictor Inserts



- 3) If the cold water is from a tank then the tank must be at least 2m above the inlet for the header tank to remain full when the pump is working at maximum rate. The pressurisation units should not be used to fill a heating system.
- 4) Check that the unit has been connected to the system using a suitable isolation valve.
- 5) Check that the mains lead has been connected to a suitably fused and switched isolator.
- 6) The cold fill pressure switches on both the Advanced and Standard are factory set to the levels listed in figure 2 as are the Hi and Lo pressure switches. If these levels are unsuitable for the installation then adjustment instructions are given in section 7.3.
- 7) Set the float to its lowest level. (fig 14)

Figure 14a. Float Adjustment Standard



Figure 14b. Float Adjustment Advanced



7.6 Filling The Unit

- 1) Check all connections and pressures. Open inlet isolation valve and fill the tank.
- 2) Undo the priming screw on pump head (fig 15). Prime until water appears. Close the screw and turn on the pump (keeping system isolation valve closed). Pump should run for a few seconds until set pressure is reached.

Figure 15a. Priming Screw Standard




Figure 15b. Priming Screw Advanced



- 3) Check for any leaks within the unit, if OK open system isolation valve and fill system via filling loop.
- 4) The unit will now monitor the system and keep it at the required pressure.

7.7 Pressure Switch Adjustment

The pressure switches are fitted with a scale to indicate the pressure at which they are set. This scale is to be used for indication only. As all the pressure switches and the pressure gauge take readings from the same place, the unit's pressure gauge can be used to give an accurate reading when setting switching levels.

The switches should be set last, after all the other commissioning tasks are complete.

Figure 16. Pressure Switch Adjustment




All the pressure switches have a nominal pressure differential (Hysteresis) of 0.4 bar. This means that there will be 0.4 bar between the pressure at which the switch changes state during a pressure rise and the pressure at which it will change when the pressure is falling again or vice versa. For example if the cold fill pressure switch is set to 3.4 bar then the switch will operate when the pressure rises to 3.4 bar causing the pump to stop. The switch will not change over & start the pump until the pressure has fallen back to 3.0 bar.

7.7.1 Pressure Switch Adjustment Apparatus

When adjusting pressure switches the unit must be set up with the apparatus similar to that shown in Figure 17 connected to the outlet.

Figure 17. Pressure Switch Adjustment Apparatus



7.7.2 Cold Fill Pressure Switch

Designed to stop the pump when pressure reaches a preset level. Setting procedure as follows:

- 1). Ensure the system pressure is lower than the pressure the switch is to be set to.
- 2). Switch the unit on.
- 3) Introduce a small leak at the outlet.
- 4) Because of the leak the unit begins a cycle of starting and stopping. Adjust the cold fill pressure switch until the starts at 0.4 bar below the required cold fill pressure.

7.7.3 Lo Pressure Switch (Advanced Only)

Designed to stop the boiler operating if the pressure falls below a preset level. Setting procedure as follows:

- 1) Set the cold fill pressure switch by following the procedure in section 7.7.2 & allow system to run to pressure.
- 2) Isolate the Weymouth unit from the mains electrical supply & from the boiler circuits
- 3) Introduce a small leak until the unit's pressure gauge reading equals the required Lo pressure setting.
- 4) Stop the leak.
- 5) The lo pressure switch is lowest on the panel which pivots around corner for easy access (see figure 23).
- 7) Set the lo pressure switch to its highest level (adjustment is shown in fig 16)
- 8) The terminals at either end of the switch form a closed circuit. Adjust the switch until the circuit is open . A meter across the two terminals will signal the change.

7.7.4 Hi Pressure Switch (Advanced Only)

Designed to stop the boiler operating if the pressure exceeds a preset level. Setting procedure follows:

- 1) Isolate the Weymouth unit from the mains electrical supply & boiler circuits.
- 2) Use the pressure source increase the pressure until the pressure gauge reads the required Hi pressure level.
- 3) Set the hi pressure switch to its lowest level (adjustment is shown in fig 16).
- 4) The terminals at either end of the switch form an open circuit. Adjust the until the circuit is closed. A meter across the terminals will signal a change.

If needed figure 25 shows the wire colours of the switches.

8.0 FAULT FINDING

General fault finding is shown in Figure 18. If the Weymouth unit still does not operate satisfactorily, consult Hamworthy Heating for assistance.

Figure 18. Fault Finding Guide.

| Fault | Possible Causes | Action |
|---|---|--|
| Pump will not run | Unit up to pressure | None |
| | No power to the unit | Check at source |
| | Isolator fuse blown | Replace fuse in isolator. Note! Investigate cause of blown fuse before restarting the unit |
| | Cold Fill Pressure switch set incorrectly | Adjust pressure switches (see section 7) |
| | Cold fill pressure switch wired incorrectly. | Check wiring against figure 25 |
| Pump runs but will not build up pressure | Pump seized or faulty | Service or replace pump (see section 10) |
| | Pump isolating valve closed (<u>Advanced</u> only) | Open valve (see fig 21) |
| | Pump not primed | Prime pump (see section 7.6) |
| | No water in tank | Check water level and investigate if necessary |
| Pump cuts in and out rapidly (hunting) | Pump non return valve jammed | Check valve |
| | Pressure switches set incorrectly | Adjust pressure switches (see section 7) |
| | Non return valve not sealing correctly | Clean valve seat or replace valve if necessary (see section 10.7) |
| Pump runs continuously | System Leak | Trace leak and ensure system is sound |
| | Cold fill pressure switch set incorrectly | Adjust pressure switches (see section 7) * |
| | Cold fill pressure switch faulty | Replace faulty switch (see section 10.5) |
| Pump cuts out at wrong pressure | System leak | Trace leak and ensure system is sound |
| | Cold fill pressure switch set incorrectly | Adjust pressure switches (see section 7) |
| Maximum system working pressure too high | Cold fill pressure switch faulty | Replace faulty switch (see section 10.5) |
| | Cold fill pressure switch set incorrectly | Adjust pressure switches (see section 7) |
| Boiler switches off unexpectedly | Cold fill pressure switch faulty | Replace faulty switch (see section 10.5) |
| | Hi or lo pressure switches set incorrectly | Adjust pressure switches (see section 7) |
| System pressure runs consistently at cold fill pressure | Hi or lo pressure switches & circuits wired incorrectly | Check wiring with Wiring diagram in appendix |
| | Small system leak | Trace leak and ensure system is sound. |

9.0 SERVICING SCHEDULE

The following is a recommended servicing schedule for the Weymouth unit and expansion vessel. If remedial action is required, refer to section 10: SERVICING AND REPLACEMENT OF COMPONENTS. If in doubt consult Hamworthy Heating.

9.1 6 Monthly

1) Check the expansion vessel charge pressure, as described in section 7.4. A significant drop in charge pressure could be due to a faulty vessel diaphragm; replacement of diaphragm should be considered. See section 10.9.

2) Briefly run the pump to check for rotor seizure. This could occur if the pump is not run for extended periods. This can be accomplished by slightly opening the expansion vessel drain valve to initiate a leak.

Note! Ensure that the drain valve is closed after this operation.

9.2 12 Monthly

1) Check the ball float valve diaphragm seat for integrity and replace if necessary. Also check the plastic float for soundness.

2) Check the expansion vessel for signs of external corrosion. If any deterioration is observed then it is recommended that the frequency of inspection be increased.

3) Check the operation of the safety circuits if utilised on the Advanced unit.

9.3 4 Yearly

1) Remove the expansion vessel diaphragm as described in section 10.9 and inspect for wear/ageing. Inspect the internal surface of the vessel for corrosion.

Significant corrosion can lead to failure of the vessel; replacement of the entire vessel should be considered. If necessary replace the diaphragm as described in section 10.9.

10.0 SERVICING AND REPLACEMENT OF COMPONENTS

Note! When servicing or replacing Weymouth components electrically isolate the unit and close the system and expansion vessel isolating valves. The Advanced unit should also be isolated from the pressure alarm circuits.

When remaking screwed connections use a thread sealant .

The cover on the Standard unit is secured by one screw at the lower edge of the front panel and one screw on the top panel. The cover on the Advanced unit is secured by one screw at the lower edge of the front panel only.

10.1 Hamworthy Heating Recommended Spares

Standard Spares

| Part | Part N° |
|----------------------------|-----------|
| Pump Assembly | 530905046 |
| Float Valve Assembly | 531911037 |
| Pressure Gauge | 557002009 |
| Pressure Switch Assembly | 533925005 |
| Non-return valve cartridge | 531911039 |

Advanced Spares

| Part | Part N° |
|----------------------------|-----------|
| Pump Assembly | 530905045 |
| Float Valve Assembly | 531911038 |
| Pressure Gauge | 557002009 |
| Pressure Switch Assembly | 533925005 |
| Non-return valve cartridge | 531911040 |

NOTE! For any service/replacement parts the unit serial No. (on the Data Plate inside the unit) **MUST** be quoted. For service or spares contacts please refer to the inside front cover of this guide.


10.2 Standard Pump Removal

Hamworthy part n° 530905046

Pump Removal Sequence


- 1) Isolate the water supply from the unit.
- 2) Empty the unit's header tank.
- 3) Once clear of water undo the bulkhead fitting (fig 19,1),
- 4) Undo the down pipe fitting (fig 19,2)
- 5) Unscrew the 2 pump assembly mounting screws (fig 19,3).
- 6) Once the pump assembly has been removed from the unit the pump can easily be removed from the assembly.

Figure 19 Pump Fittings



The wiring terminals are inside the box on the top on the pump. The wiring layout can be found on the wiring diagram in the appendix and on Figure 20 below.

Figure 20 Standard Pump Wiring Terminals



10.3 Advanced Pump Removal (part n° 530805045)

- 1) Isolate water by turning screw in ball valve see fig 21 bellow.
- 2) Disconnect the last grey elbow fitting using the blue tool provided. Take care to line up the tool correctly before pushing the tool into the fitting to release the pipe (see fig 22).
- 3) The pressure switch assembly can be pulled forwards (pivots on left corners see fig 23)
- 4) Disconnect the outlet pipe from the pump. Remove the quick release clip first (see fig 24)
- 5) Disconnect the wiring on the mains terminal (see fig 25)
- 6) The pump assembly including the mounting plate can now be removed from the unit.
- 7) When the pump assembly has been removed the pump can easily be removed from the assembly.

Figure 21



Figure 22



Figure 23




Figure 24



The power lead from the pump is connected to the mains terminal on the back wall of the unit. The connections are shown in Figure 25 below.

Figure 25 Weymouth Advanced Pump Wiring Terminal



10.3.1 Pump Fitting On Both Units

Pump fitting for each unit is basically the reverse of pump removal.

Care should be taken not to over tighten the 2 pump mounting screws on the Standard units as this can shear the welded thread. Once re-fitted and connected the pump needs to be bled. Instructions of this can be found in section 7.6.

10.4 Inlet Valve On Both Units (part n°s 531911037 Standard & 531911038 Advanced)

The inlet valve and float in the header tank are supplied as one assembly (see fig 14a and 14b). The removal/replacement procedure is the same for both units.

- 1) Isolate the unit from the water supply.
- 2) Undo 1/2" BSP connection to remove supply pipe.
- 3) Unscrew the lock nut from the inlet tube. The valve and float are now free to be removed.
- 4) On the standard unit there is a black spacer which fits between the tank and the chassis. This must be refitted when a new assembly is installed.
- 5) Once fitted the float adjustment should be set to the lowest level (see section 7.5)

10.5 Pressure Switches On Both Units (part n° 533925005)

- 1) Undo the capillary nut holding the end into the pipe (see fig 26).
- 2) Take off the wires. The cold fill pressure switch on both units is connected to two orange wires which can be reconnected any way round. The Hi and Lo pressure switches (Advanced only) must be reconnected as shown in fig 27.
- 3) Pressure switch must be set to correct level. Setting instructions are given in section 7.

Figure 26 Capillary Nut





Figure 27 Switch Wiring

(Advanced Only)

10.6 Pressure Gauge On Both Units. (part n° 537002009)

- 1) Undo the capillary nut holding the end into the pipe (see fig 26).
- 2) Depress the tags on the opposite sides of the gauge body and push through the panel (see fig 28)

Figure 28 Pressure Gauge



10.7 Non-Return Valve On Standard Unit (part n° 531911039)

- 1) Follow the procedure for removal of the pump (see section 10.2). The non-return valve is inside the brass fitting shown in figure 29.
- 2) Unscrew the brass fitting from the silver nut it is screwed into.
- 3) Push the valve out from the brass fitting as shown in figure 30.

Figure 29



Figure 30



10.8 Non-Return Valve On Advanced Unit (part n° 531911040)

- 1) Follow the procedure for removal of the pump (see section 10.3). The valve is inside the brass quick release fitting shown in figure 31.
- 2) Unscrew the brass fitting from pump.
- 3) Push the valve out from the brass fitting (see fig 30).

Figure 31



10.9 System Expansion Vessel Diaphragm

(Part n° dependant on model and serial n°. Consult Hamworthy Heating for details)

- 1) Turn off the boiler and electrically isolate the unit.
- 2) Close the system isolating valve and isolate the mains water supply to the header tank.
- 3) Drain the pressurisation unit and expansion vessel. **Note!** Leave the drain cock open. Disconnect the expansion vessel pipe-work.
- 4) Unscrew the diaphragm top connection (normally a brass nut at the opposite end to the water entry).
- 5) Remove the bolts from the flange at the base of the vessel and remove the diaphragm.
- 6) To replace the diaphragm top connection (normally a brass nut at the opposite end to the water entry).
- 7) Screw the plug lightly into the diaphragm top connection and pull it up through the expansion vessel.
- 8) Lockup the diaphragm top connection and tighten the water connection flange screws. Note! Ensure that the diaphragm is not twisted.
- 9) Reconnect the expansion vessel pipe-work.
- 10) To restart the system follow the steps in section 7.

APPENDIX

| Contents | Page |
|--|-------------|
| Figure A1 Wiring Diagrams | 19 |
| Figure A2 Heating System Calculation Sheet | 20 |

Figure A1. Wiring Diagrams





Figure A2 - Heating System Calculation Sheet

1. System Parameters

System Water Content - $V_s =$ litres
 System Anti-freeze Content - $ra =$ %
 Maximum System Working Pressure - $P_w =$ bar
 Maximum Static Head - $P_h =$ metres

Example

$V_s = 2000$ litres
 $ra = 10\%$
 $P_w = 8$ bar
 $P_h = 22$ m

If the system volume is not known then the following rule of thumb can be applied:

$$\text{System water content} = \text{Boiler power (KW)} \times 10$$

2. Expansion Vessel Volume Calculation, V_v -

$$V_v = \frac{(ra + 81.5) \times V_s}{921} = \frac{(\text{} + 81.5) \times \text{}}{921} \quad V_v = \text{} \text{ litres}$$

$$V_v = \frac{(10+81.5) \times 2000}{921} = 199$$

If the system is to be set up using the factory preset pressure switch levels for the Weymouth unit then no other calculations are necessary. The factory preset switch levels are:

Cold Fill Pressure Switching Level, $P_f = 1.8$ bar
 Hi Pressure Switching Level, $P_{hi} = 3.65$ bar
 Lo Pressure Switching Level, $P_{lo} = 1.5$ bar

The safety valve lift pressure should be set 0.35 bar above the Hi pressure switching level.

3. Cold Fill Pressure Switch Setting Calculation, P_f -

$$P_f = \frac{P_h}{10.2} + 0.2 = \frac{\text{}}{10.2} + 0.2 \quad P_f = \text{} \text{ bar}$$

$$P_f = \frac{22}{10.2} + 0.2 = 2.35$$

4. Safety Valve Lift Pressure Calculation, P_s -

Actual fitted expansion vessel volume, V_{va} - litres
 Actual fitted expansion vessel acceptance factor, a_{va} -

$$a_{va} = \frac{V_v \times 0.35}{V_{va}} = \frac{\text{} \times 0.35}{\text{}} \quad a_{va} = \text{}$$

$$V_{va} = 300$$

$$a_{va} = 0.23$$

Actual working pressure, P_{wa} -

$$P_{wa} = \frac{P_f + a_{va}}{1 - a_{va}} = \frac{\text{} + \text{}}{1 - \text{}} \quad P_{wa} = \text{} \text{ bar}$$

$$P_{wa} = \frac{2.35 + 0.23}{1 - 0.23} = 3.35$$

Note! If $P_{wa} > P_w$ then increase expansion vessel volume, V_{va} and recalculate from step start of step 3

$$P_s = P_{wa} + 0.7 = \text{} + 0.7 \quad P_s = \text{} \text{ bar}$$

$$P_s = 3.35 + 0.7 = 4.05$$

5. Calculation of Expansion Vessel Acceptance Factor at Safety Valve Lift Pressure, a_s -

$$a_s = \frac{P_s - P_f}{P_s - 1} = \frac{\text{} - \text{}}{\text{} - 1} \quad a_s = \text{}$$

$$a_s = \frac{4.05 - 2.35}{4.05 - 1} = 0.56$$

Note! If $a_s > 0.5$ then increase expansion vessel volume, V_{va} and recalculate from step start of step 3

6. Lo Pressure Switch Setting Calculation, P_{sl} -

$$P_{sl} = P_f - 0.3 = \text{} - 0.3 \quad P_{sl} = \text{} \text{ bar}$$


$$P_{sl} = 2.05$$

7. Hi Pressure Switch Setting Calculation, P_{sh} -

$$P_{sh} = P_{wa} - 0.35 = \text{} - 0.35 \quad P_{sh} = \text{} \text{ bar}$$

$$P_{wa} = 3.0$$

Notes



Connect direct






Direct Dial Telephone and Fax Numbers



- boilers
- controllers
- water heaters
- pressurisation sets

Poole Office

Hamworthy Heating Limited
Fleets Corner, Poole, Dorset BH17 0HH England
Main switchboard tel: **01202 662500**

| | | |
|---------------------|--|---|
| Technical enquiries |  01202 662527/662528 |  01202 665111 |
| Spare parts |  01202 662525 |  01202 665111 |
| Service department |  01202 662555 |  01202 662522 |



- flue components
- packaged fan dilution systems
- bespoke flue components
- bespoke flue systems
- design and installation

Birmingham Office

Hamworthy Heating Limited
Shady Lane, Great Barr, Birmingham B44 9ER
Main switchboard tel: **0121 360 7000** fax: **0121 325 2309**

General enquiries  **0121 360 7000**

Direct Email Addresses

Customer Services spares@hamworthy-heating.com
service@hamworthy-heating.com
technical@hamworthy-heating.com
sales.flues@hamworthy-heating.com

Hamworthy Heating Accredited Agents

North West England

Gillies Modular Services
210-218 New Chester Road, Birkenhead, Merseyside L41 9BG
tel: **0151 666 1030** fax: **0151 647 8101**

Southern Ireland

HEVAC Limited
Naas Road, Dublin 12, Ireland
tel: **00 3531 141 91919** fax: **00 3531 145 84806**

Northern Ireland

HVAC Supplies Limited
Unit 2, Antrim Line Business Park, Sentry Lane, Newtownabbey BT36 8XX
tel: **02890 849826** fax: **02890 847443**

Scotland

McDowall Modular Services
14-46 Lomond Street, Glasgow, Scotland G22 6JD
tel: **0141 336 8795** fax: **0141 336 8954**

North East England

Allison Heating Products
17 Beech Road, South Shields, Tyne & Wear NE33 2QH
tel: **0191 455 7898** fax: **0191 455 7899**

Website

www.hamworthy-heating.com

Associate Companies, Offices and Agents throughout the World.

Hamworthy reserves the right to make changes and improvements which may necessitate alteration to the specification without prior notice.